
headphone
Foot switch
CD player etc.
OUTPUT
FOOT SW
AUX
INPUT
DC4.5V
USB
AC adapter
Computer
guitar or bass
KORG
RH450
CLASS-D BASS AMPLIFIER
CAUTION
MAINS IN
100-240VAC~ 50/60Hz
85W @ 1/8 of Max. Output
SPEAKER OUT
speakon w/ center 1/4" jack
4 Ohm
minimum Load
REMOTE IN
5V/100mA
DIGITAL OUT
PRE/POST PREAMP
AUX IN
rehearse
LINE DRIVER OUT
transformer balanced
AES/EBU 96kHz
(S/PDIF Compatible)
PRE
POST
PRE/POST
PRE-AMPLIFIER
MAINS GROUND MUST BE CONNECTED
ALLOWED SPEAKER FREE OPERATION
Left
Right
2,2 kOhm